



PANEL SHOWN ON ITS SIDE FOR REFERENCE ONLY  
 DIMENSIONS ARE SHOWN IN INCH AND [MILLIMETERS]

THIS TEMPLATE HAS BEEN PROVIDED TO HELP YOU IN INSTALLING YOUR NEW BLUE SEA SYSTEMS POWER DISTRIBUTION PANEL.



425 Sequoia Drive Bellingham, WA 98226  
[www.blueseasystems.com](http://www.blueseasystems.com)

PANEL CUTOUT DIMENSIONS FOR 10 POSITION METER PANEL

DATE	SCALE	DOCUMENT NO.	REVISION	SHEET
3-30-00	NOT TO SCALE	9967-C	C	1 OF 1